

Snap Lights

INSTALLING C9/C7 LIGHTS ON SURFACES USING CARRIAGE SNAPS AND SCREW SNAPS EXAMPLES: FASCIA/POROUS SURFACES/LEAF GUARDS

Here are some suggested steps when installing lights on Fascia:

SUGGESTED STEPS FOR INSTALLING C9/C7 LIGHTS ON FASCIA :

1. Install the Carriage Snap around the housing of the C9 or C7 bulbs (See tip below)
2. Make a pilot hole where you want to install the first Screw Snap/C9/C7 light
3. Screw in the screw
4. Attach the Carriage Snap to the Screw Snap
5. Pull the wire to determine the next spot for the screw
6. Repeat the process

HELPFUL TIPS WHEN USING THE CARRIAGE SNAP AND SCREW SNAP:

- You can make the C9/C7 lights point up, down, or straight out using the Carriage Snap. To have the lights point out, place the housing of the light inside the carriage. Slide one side of the wire in one bottom slot and the other side of the wire in the other bottom slot. It helps if you twist and slide in the slot at the same time. It will be a snug fit so it will not fall off. To point lights up or down, slide the wire through the top slots of the Carriage Snap and push in all the way.
- When making a pilot hole, I found that I could easily make the pilot hole by hand with the tip of a flat wood boring bit. Then, use a power drill to screw in the Screw Snap after the pilot hole is made.
- When removing lights from the fascia, keep the Carriage Snap on the C9/C7 light. For installation next year, just snap it back up where it was before.
- If the Screw Snap is on the front of the fascia, you can spray paint the screw first to better match the screw color to the fascia color.
- If you want to hide the Screw Snap and the wire, you can install the Screw Snap behind the Fascia. Position the Screw Snap so that when the Carriage Snap is attached only the light bulb appears under the Fascia.

* **NOTE** – If using **SPT-2 wire**, consider using a screw driver to flatten the small ridges inside the slots (of the Carriage Snap) to provide more space for the wire.

Snap Lights

INSTALLING C9/C7 LIGHTS USING CARRIAGE SNAPS AND STICKY SNAPS

Here are some suggested steps when installing lights around **windows/railings**:

SUGGESTED STEPS:

1. First, install the Carriage Snap around the housing of the C9 or C7 bulbs (See first tip below)
2. Ensure that the surface you are installing the Sticky Snap on is clean
3. Snap the Sticky Snap on the bottom of the Carriage Snap
4. Peel the red 3M cover off the back of the Sticky Snap.
5. Place the Sticky Snap on the frame around the window (often vinyl or metal) where you want to install the light.
6. Hold for about 10 seconds.

HELPFUL TIPS:

- You can make the C9/C7 lights point up, down, or straight out using the Carriage Snap. To have the lights point out, place the housing of the light inside the carriage. Slide one side of the wire in one bottom slot and the other side of the wire in the other bottom slot. It helps if you twist and slide in the slot at the same time. It will be a snug fit so it will not fall off. To point lights up or down, slide the wire through the top slots of the Carriage Snap and push in all the way.
- Do not touch the sticky back or it will lose its stick due to the oils on your finger
- To match the window frame, spray paint the top of the Sticky Snap beforehand and allow to dry
- When removing lights, keep the snap on the window frame. You may want to secure the snap with your finger when unsnapping the lights.
- Included screws can be used with the Carriage Snap on porous surfaces (i.e. on or behind fascia, tree trunks/limbs, etc.)

* **NOTE** – If using **SPT-2 wire**, consider using a screw driver to flatten the small ridges inside the slots (of the Carriage Snap) to provide more space for the wire.